

Quality Service

Great all-inclusive prices include:

● = included in service

	TYPE OF SERVICE		
	MAJOR SERVICE	INTERIM SERVICE	DIESEL SERVICE
SERVICE PREPARATION			
Fit FastFit service protection	●	●	●
Check for body damage	●	●	●
Check wheel trims	●	●	●
BEFORE RAISING VEHICLE			
Check exterior and interior lights	●	●	●
Check horns	●	●	●
Check ABS warning lights for correct operation	●	●	●
Check heater plug indicator	●	●	●
Check seat belts, front and rear	●	●	●
Check for correct clutch action/clutch slip	●	●	●
Check windscreen wiper condition	●	●	●
Check windscreen washer alignment	●	●	●
Check windscreen condition	●	●	●
Check mirror condition	●	●	●
Check number plate condition	●	●	●
Check fuel cap condition	●	●	●
Check headlamp condition	●	●	●

UNDER BONNET			
Check condition of HT leads	●	●	
Check air filter		●	
Check electric cooling fan for operation (where applicable)	●		●
Check for timing/cam belt replacement	●		●
Check for cabin/pollen filter replacement	●		●
Check radiator for leaks	●		●
Check condition of radiator cap	●		●
Check expansion bottle and cap for leaks	●		●
Check anti-freeze strength	●	●	●
Check radiator hoses for leaks and condition	●	●	●
Check auxiliary drive belts	●	●	●
Check battery terminals; security	●	●	●
Check clutch hydraulics/cable	●	●	●
Adjust clutch hydraulics/cable (if required)	●	●	●
Check vehicle for coolant leak (visual)	●	●	●

RAISE VEHICLE			
Check wheel bearings for play and noise	●	●	●
Check steering/suspension components for wear, corrosion and leaks	●	●	●
Remove wheels and brake drums; check discs/drums for wear, cracks, distortion, corrosion and scoring	●	●	●
Inspect wheel cylinders/calipers for leaks and operation	●	●	●
Check pads/shoes for wear	●	●	●
Visually check brake hydraulic system, pipes and hoses for leaks, chafing and corrosion	●	●	●
Check security of handbrake linkages and travel; lubricate and adjust	●	●	●
Check tyre condition, including spare	●	●	●

● = included in service

	TYPE OF SERVICE		
	MAJOR SERVICE	INTERIM SERVICE	DIESEL SERVICE
RAISE VEHICLE(CONTINUED)			
Check and adjust tyre pressure, including spare	●	●	●
Check propshaft/driveshaft, joints and gaiters for condition	●	●	●
Inspect exhaust system for leaks, security and noise	●	●	●
Check vehicle for oil leaks (visual)	●	●	●
Lubricate auto transmission, cable/linkage	●	●	●
Check condition of fuel lines/filter	●	●	●
Check wheel balance including spare	●	●	●
Check auxiliary handbrake shoes (where applicable)	●	●	●

DIAGNOSTICS			
Test starter motor for cranking operation & security	●		●
Test alternator for charging operation & security	●		●
Carry out battery test	●		●

MAINTENANCE			
Renew oil filter and sump-plug washer	●	●	●
Check/top up gearbox and axle oils	●	●	●
Renew engine oil	●	●	●
Check condition of spark plugs	●	●	●
Top up brake/clutch fluid	●	●	●
Top up radiator	●	●	●
Lubricate battery terminals	●	●	●
Lubricate throttle linkages	●	●	●
Renew air filter	●	●	●
Check/top up auto transmission fluid	●	●	●
Check/top up power steering reservoir	●	●	●
Grease bonnet catch	●	●	●
Lubricate accessible door/bonnet hinges	●	●	●

VEHICLE ON LEVEL			
Check wheel nuts for security	●	●	●
Check front wheel alignment	●	●	●
Check bonnet security	●	●	●
Reset vehicle service light (where applicable)	●	●	●
Stamp service history book	●	●	●
Road test vehicle	●	●	●

...and ONLY best quality branded parts!



www.fastfitstation.com